



How to Demonstrate the Resolution and Advantages of Arecont Vision Megapixel Video Clips in Exacq Media Player



How to Use Digital PTZ



- Double click to open the video clip
- Play or pause the clip
- Right click on image to open menu
- Go to Digital PTZ and click to enable



- Once enabled, there are 3 ways to Digitally PTZ
 1. Use the scroll on your mouse to zoom in-out. Pan side to side – up and down by clicking on the arrow in the direction you want to pan or tilt.
 2. Use page up – down keys to zoom in-out. Arrow keys to go side to side.
 3. Hold down ctrl key and left mouse, draw a box around the area of the image you want to zoom in on.

How to Show Regions of Interest from a Single Camera

- Double click to open the video clip
- Choose the multiple window view
- Drag the camera into each of the screens
- Enable and digitally zoom into different regions within three of the four windows
- Press play or drag the timeline cursor to show that these can all be played back simultaneously

How to Show Panoramic Video Clips

- Double click to open the video clip
- Choose the multiple window view that has 4 across.
- Press play to bring up video in all four windows.
- If they are out of order, press pause and drag each image into the correct window to provide the 180 degree, panoramic view.
- Play the clip
- Pause and double click on one of the windows to bring it full screen and digitally zoom to show detail, in this case a license plate.

